



RigidCORE

INSTALLATION INSTRUCTIONS

INSTALLER / OWNER RESPONSIBILITIES

Prior to installing the flooring the Installer must confirm all visual aspects of the flooring and approve job site conditions. The installer and/or owner, have the following responsibilities:

- 1.) Understanding how the floor will look once installed – the installer and owner must meet prior to installation to review:
 - a. How was the floor chosen? Review the control samples, (the samples from which the floor was chosen), and compare to the actual flooring batch onsite prior to installation making sure it meets the owner’s expectations as to:
 - i. Color/Style – Is the flooring the correct color per the owners expectations?
 - ii. Color Variation, Batch to Batch – inspect the carton label production run of flooring you received and make sure it meets your expectations. Layout several cartons of material to confirm lots can be mixed.
 - iii. Finish – Is the gloss correct? Does the look of the finish meet the owner’s expectations? Does the owner understand that care must be taken during the installation, move-in and in-use?
 - b. Congratulations! You have now made sure that the owner will not be disappointed once the flooring is installed and they see it for the first time. The person installing the floor is responsible for visual issues once the flooring is installed.
- 2.) Installer responsibilities during installation:
 - a. Receive the floor and make sure it is as ordered and meets the owner’s expectations.
 - b. Test the subfloor and flooring for temperature on site to make sure the flooring will perform satisfactorily on this installation. If the flooring is being installed over concrete use non-compressing moisture/vapor barrier (e.g. 6 mil polyfilm) to avoid issues in the concrete should subsequently absorb moisture.
 - c. Follow these Installation Instructions.
 - d. Select out any pieces with visible defects and stop the installation should a reoccurring problem be found, (over the 5% allowed by industry practices). DO NOT INSTALL pieces with visible defects.
- 3.) Keep a Permanent Job Record and provide a copy to the owner.
- 4.) Make sure the owner understands how to maintain the floor. Give them a copy of the Maintenance Instructions & Product Warranty.

DO NOT: Do not install this product over residual asphalt-type (cut back) adhesive. Cover with underlayment plywood to avoid bleeding through.

DO NOT: Do not install product with visible defect. This product is manufactured to high quality inspection standards but boxes can have occasional defective product contained inside. If you notice excessive defect stop the installation immediately and call your local retailer. The manufacturer is not responsible for visually defective material installed.

PRE-INSTALLATION JOBSITE REQUIREMENTS

Carefully examine the flooring prior to installation for color, finish and quality. Ensure adequate lighting for proper inspection and make sure you review all different lots of material before beginning. If flooring is not acceptable, contact your retailer or distributor immediately and arrange for replacement. We are not responsible for flooring installed with visible defects. Prior to installation of any flooring, the installer must ensure that the jobsite and subfloor meet the requirements of these instructions. We are not responsible for flooring failure resulting from unsatisfactory jobsite and/or subfloor conditions.

Room temperature and humidity of installation area should be consistent with normal, year-round living conditions for at least a week before installation of flooring. Room humidity range of 35-65% is recommended. The maximum distance the flooring can be assembled without a transition molding (for additional expansion space) is 65 feet. The temperature should stay between 55° – 100° Fahrenheit at all times. Surface temperatures of less than -20° F (-29° C) or above 150° F (65°C) or greater voids the product warranty.

Although acclimation is not specifically required, it is best practice that the product is installed close to the intended temperature of the dwelling. Between 55° F (13° C) and 100° F (38° C) is allowed, but a target of 70° F (21° C) is ideal. Do not store the boxes of flooring directly on concrete. Test each box of flooring to confirm the plank is in the required temperature range prior to installation.

PRE-INSTALLATION SUBFLOOR REQUIREMENTS

All patch work and preparation to the subfloor must be done and allowed to dry prior to starting the installation.

The subfloor must be FLAT, SECURE, and DRY. If the flooring is being installed over concrete use non-compressing moisture/vapor barrier (e.g. 6 mil polyfilm) to avoid issues if the concrete should subsequently absorb moisture.

Check cartons and leave one or two box labels with the end user. Mix different batch or lot numbers from several boxes, to blend shade variation. If the product looks incorrect stop the installation immediately and call your local retailer.

All Subfloors must be:

- Structurally sound
- Clean: Thoroughly swept and free of all debris
- Level: Flat to 3/16" per 10-foot radius
- Dry and will remain dry: Subfloor must remain dry year-round. Moisture content of wood sub floors must not exceed 11%, concrete must not exceed 3.5 as measured with a Commercial Concrete Moisture Meter

Proper subfloor preparation and suitable underlayment installation are essential for a trouble-free job. Uneven or rough subfloor surfaces could show through (or telegraph) to the surface of this product resulting in an unsightly surface and can make high spots more susceptible to excessive wear. Correct the subfloor imperfections before you begin installing this product.

NON-APPROVED SUBSTRATES

Remove the floors noted below and remove old adhesive before installing Paramount RigidCORE.

- Any additional underlayment pad
- Carpeting/Carpet Pad
- Cushion Back Sheet Vinyl
- Engineered Hardwood Over Concrete
- Floating Floors
- Hardwood Over Concrete
- Parquet Over Concrete
- Sleeper Substrates

Wood Sub Floors - Wood subfloors must be rigid and suspended at least 18" above the ground with adequate cross ventilation. Crawl space ground must be covered with suitable vapor barrier. Do not install this product over a wood subfloor which is directly on top of a concrete substrate or sleeper system.

If an existing wood subfloor is damaged or not of underlayment grade one must be put in place prior to beginning the installation of this product. The approved underlayment should provide a smooth, sturdy, and even surface for this product.

Wood underlayment panels should be dimensionally stable. Wood underlayment panels should be smooth and fully sanded so the graining or texturing will not show through. Wood underlayment panels should be resistant to both static and impact indentation. Wood underlayment panels should be free from any surface components that may cause staining such as plastic fillers, marking inks, sealers, etc. Wood panels should be uniform density, porosity and thickness. Wood underlayment panels must have a written warranty for suitability and performance from the panel manufacturer or have a history of proven performance.

Underlayment panels should be installed with the face grain running across the joists. Panels should be lightly butted against each other, not forced tight. End joints of the panels should be offset at least 16". Start the installation in one corner and work diagonally across the floor. Use only non-staining fasteners.

Do not use common steel, cement coated or some nails that are resin/rosin coated. It is not recommended to glue and screw down underlayment panels as some solvent based adhesives are known to stain vinyl flooring coverings. Fasteners should be staggered and no more than 4" apart around the perimeter and no more than 3/8" from the edges (6" apart across the middle of the panel). Fasteners must set flush or slightly below the surface of the underlayment. Any unevenness must be sanded level. Gaps, hammer indentations, and all other surface irregularities must be patched with a non-shrinking, water resistant Portland cementitious based patching underlayment compound.

Concrete Sub Floors - Over concrete use a non-compressing moisture/vapor barrier (e.g. 6 mil polyfilm) to avoid issues if the concrete subsequently absorbs moisture. Concrete subfloors must be dry, smooth and free from dust, dirt, solvent, paint, wax, grease, oil, asphalt sealing compounds and other extraneous materials. The surface must be hard and dense and free from powder or flaking.

New concrete slabs must be allowed to dry and completely prior to beginning the installation of this product, which take at least 6 weeks. Curing agents, surface hardeners and other additives may cause adhesive bond failure in the case adhesives are used. All concrete subfloors must be checked for moisture and alkalinity before installing this product. Do not install over any subfloor with moisture emissions higher than 5 lbs. per 1000 sq. ft. per 24 hours per a calcium chloride test. We are not responsible for shrinking or mildew caused by site conditions.

As in wood subfloor systems, all holes, grooves, expansion joints, and other depressions must be filled with a latex underlayment compound and troweled smooth and feathered even with the surrounding surface.

Ceramic tile, resilient tile and non-cushioned sheet vinyl covered Subfloors - must be well-bonded to subfloor, in good condition, clean and level. Ceramic tile unevenness should be made smooth by applying an overlay such as cementitious patching or leveling compound. Do not sand existing vinyl floors, as they may contain asbestos. **WARNING:** Do not sand, dry scrape, bead blast or mechanically pulverize existing resilient flooring, backing or lining felt. These products may contain asbestos fibers that are not readily identifiable. Using the above non-recommended procedures on asbestos containing material can create asbestos dust. The inhalation of asbestos dust may cause cancer or other serious bodily harm.

The final responsibility lies with the installer for approving the condition of the subfloor and its impact on the final look of this product.

Installing Cabinets on Top of Floor (residential only)

When cabinets are installed on top of RigidCORE Flooring the subfloor must be perfectly flat and secure. If cabinets are to be secured one cannot do so using nails or screws through the flooring product. Cabinets are to be secured to the wall but not through the flooring. Expansion space is required around pipes and other fixed objects.


Radiant Heat

This product is approved for radiant heat, use only floating installation over radiant heat. Subfloor should not exceed 80°F. A data logger may be required for this product over radiant heat. Check with radiant heat manufacturer suggested guidelines to limit the maximum water temperature inside heating pipes. Switch off heating unit one or two days before flooring installation and bring heat up slowly after installation.

Temperature Extremes

Paramount RigidCORE can be installed a wide range of temperatures. However, it should not be installed in any situation where the installation location may experience surface temperatures of less than -20° F (-29° C) or above 150° F (65°C).

PRODUCT INSTALLATION (HERRINGBONE)



A and B Panels:

Two different types of panels are used to install the herringbone pattern. Identify and sort the A and B panels to make installation easier. Always work with the groove underside going away from the wall.*



Door Mouldings and Skirtings:

Put a panel (with decorative side down) next to the door moulding and saw as shown in figure 1. Then slide the panel under the moulding.





Figure 1

1. Getting Started: Choose a wall to start at and begin installing at the left corner. Start with an A-panel and place it with its long side marking facing the left wall at an angle of 45°. Make sure that the distance between the left wall and the panel is less than the length of one panel.






2. Connect Next Panel: Continue with a B-panel. Press the long side of the B-panel at an angle against the short side of the previous installed A-panel. Fold down the B-panel flat to the floor to lock the panels tightly together. Check that the grooves on the two panels form a continuous line.






3. Connect Additional Panels: Next panel is an A-panel. Again, press the long side of the new A-panel at an angle against the short side of the previous B-panel and fold down. Continue like this with as many panels as may fit along the starting wall.



4. Center the First Row: Check that the first row of panels is centered along the starting wall. Make sure that the distance to the walls on both sides are less than the length of one panel. If not, add a panel at the right side.



5. Cut the End Panels to Size: Measure and cut the end panels to size using a fine-toothed saw. Finish the first row with the cut end panels. Make sure that you leave a gap of 1/4" to each wall.





6. Start the Second Row: Start the next row with an A-panel. Place the new panel against the previous row and fold down.






7. Install the A-Panels: Continue from the left to the right and install all the A-panels in the second row. Finish with a piece of panel cut to size (step 5).



8. Continue with the B-Panels: Now work in the opposite direction, from the right to the left and install all the B-panels in the second row. Finish with a piece of panel cut to size (step 5).






9. Complete Four Rows: install additional rows to complete four full rows.





10. Adjust the Starting Rows: The first four rows have to be cut parallel to the wall. Measure and mark where to cut the floor panels at a fixed/parallel distance to the wall.





11. Dismantle and Cut: Number the panels from 1 to your end panel. This will allow you to keep the panels in order. Dismantle the panels and cut them to size along the previous marked line.



12. Install the Starting Triangles: Connect the cut starting panels to form triangular shapes, one by one. Start installing the triangles from the left corner. It is recommended to use glue to fix the smallest parts of the triangles into place by applying a small quantity of glue inside the groove.








13. Install a few more rows: Connect the triangles by installing a few additional rows of panels. Start each row from the left to the right with the A-panels, finish with the cut piece of panel (step 5) and then install all the B-panels in the row. Finish with the left end panel, cut to size.




14. Put in Spacers: Put in spacers between the flooring and the wall to ensure an expansion gap of 1/4".

15. Subsequent Rows: Start each subsequent row by installing the A-panels from the left to the right and complete the row by laying the B-panels from the right to the left.

16. Last Row: Measure and cut the panels in the last row to size. It is recommended to use glue to install the smallest piece of panels. Apply a small quantity of glue inside the groove.



17. **Spacing and Skirting:** Remove the spacers and cover the expansion gap with wall base and/or quarter round mouldings.



*If installing RigidCORE Herringbone in an environment that has a length greater than 65', a T-Molding should be utilized to separate the floor into separate sections no larger than 65' lineal feet in any direction.

CLEANING & MAINTENANCE

Preventative Maintenance calls for clean protective mats in front of any doors leading to the outside. This helps limit the amount of sand and grit from getting on to your RigidCORE floors. Gritty sand is any floor coverings worst enemy. Install proper floor protectors of furniture legs used on RigidCORE flooring. Protectors will allow chairs to move easily over the floor without scuffing or scratching. Clean the protectors on a regular basis to remove any grit that may have become embedded. Do not wax the bottom of furniture legs. To keep you floor looking it's best, dust mop or vacuum your floor frequently. Do not use household dust treatment chemical of any kind as this may cause the floor to become slick or dull the finish. Simply sweep the floor as needed. Do not pour pails of water on your floor to clean or use excessive water. This can damage your subfloor. Do not allow pets with unclipped nails to walk on the vinyl floor. It could cause severe scratching to the surface.

Regular Maintenance calls for food spills to be cleaned up as quickly as possible. Avoid acidic or abrasive all-purpose cleaners, powdered cleaners, oil soaps, dish washing detergents, and dusting products. Shoe marks and scuffs can be removed by spot cleaning with a non-abrasive all purpose cleaner and a non-abrasive scrubbing pad. Regular household dirt can cleaned by damp cleaning with warm soapy water. Always sweep and vacuum your RigidCORE floor before cleaning. Do not wax the surface of this product.

If accidental deep scratches occur then it might be necessary to replace individual planks or tiles. Always retain some extra product for this instance. If the damaged plank is along the perimeter of the room, the easiest technique is to just disconnect the planks until the damaged plank is removed. If it is impractical to disconnect and reassemble the flooring the following procedure should be used.

- Using a circular saw and or a multi-tool saw, cut out and remove the center of the damaged piece, leaving approximately a 1" strip attached to the surrounding material.
- Carefully cut back from the corners of the plank or tile to the inside edge.
- Remove the edges by wiggling the cut plank out from the tongue and groove of the surrounding pieces.
- Prepare the replacement plank by removing the leading edge of the tongue profile on the long side and the end of the plank being careful not to damage the decorative surface. Also remove the bottom of the groove on the short end side by cutting on an angle. Once the plank is prepared install the groove into the tongue to test the fit.

- Position the replacement piece by engaging the groove into the tongue of the adjoining material.
- Hinge the prepared replacement plank into position.
- Slightly lift the prepared side of the plank and apply a thin application of seam sealer onto the three exposed seams and carefully position the plank into place, wipe any excess from the surface.
- Use a hand roller to assist in aligning the edges into position.
- Weight down the replaced plank for at least 15 minutes until the sealer secures the material.

MISCELLANEOUS

Heavy Furniture should be equipped with suitable non-staining, wide-bearing casters or protectors.

Non-staining felt protectors for table and chair legs to help prevent scratching.

Close your curtains or blinds where extreme sunlight hits the floor. During peak sunlight hours, the use of blinds or drapes is recommended.

AFTER THE INSTALLATION IS COMPLETE, LEAVE A COPY OF THE PRODUCT WARRANTY OBTAINED FROM YOUR RETAILER OR FROM WHOM YOU PURCHASED THE FLOORING WITH THE OWNER.

