

HOW TO ENGAGE ON LONG SIDE - ANGLE ON LONG SIDE





Figure 1a. To begin lay 2 planks next to each other on the long edge.

Gently click the planks together on a 30°-angle until the plank is engaged as shown in figures: 1b, 1c, & 1d. You can visually tell if the plank is engaged if the edges are sealed and have no gaps. A proper engagement should lay flat as shown in figure 1d, you can lift the board slightly to check for a tight fit.

HOW TO ENGAGE ON SHORT SIDE - TAP WITH TAPPING BLOCK SHORT SIDE






Figure 2. Place the next plank on the long edge and repeat the same step. Bring the engaged plank so it meets the short end joint as shown in figure 2. Place an extra plank on the outside to help guide the plank in place.

With a hard rubber mallet and tapping block tap the short end gently until the other side is engaged. Please make sure you use a tapping block with a profile as shown in figure 3a so that you do not damage the lip of the plank. To avoid damaging the planks you must tap them together gradually. A proper joint should be laid flat, you can lift the board slightly to check for a tight fit. Once engaged you can remove the extra plank and use it again. Repeat these steps to ensure a successful installation.

DO'S & DON'TS OF SHORT SIDE ENGAGEMENT

